

TechNexion kernel 3.14.52 release notes

v1.03

TABLE OF CONTENTS

1. Overview.....	5
1.1. Contents.....	5
1.2. Supported products.....	5
2. Usage instructions.....	7
2.1. Setting up a build environment.....	7
2.2. Preparing a bootable SD card.....	7
2.3. U-boot bootloader.....	8
2.3.1. Compiling u-boot.....	8
2.3.2. Installing u-boot.....	9
2.4. Linux kernel.....	10
2.4.1. Compiling the kernel.....	10
2.4.2. Installing the linux kernel, device trees and modules.....	11
2.5. Installing WIFI and bluetooth firmware.....	12
3.0 Usage.....	13
3.1. Serial debug console.....	13
3.2. Enabling WiFi.....	13
3.2.1 Loading driver and firmware.....	13
3.2.2 Verifying WiFi operation.....	14
3.3. Enabling bluetooth.....	14
3.3.1. Loading bluetooth driver and firmware.....	14
3.3.2. Verify Bluetooth functionality.....	15
4.0 Customization.....	16
4.1. Display settings	16
4.1.1. Change output device.....	16
4.1.2. Change display parameters.....	17
4.2. Boot splash screen.....	18
5.0. Troubleshooting.....	20
5.1. It is not working!.....	20
5.2. Debug console problems.....	20
5.2.1. There is nothing on the console!.....	20

[5.2.2. There is still nothing on the console on my TC070020](#)
[5.2.3. Garbage on the console.....21](#)
[5.3. Wifi and bluetooth problems.....21](#)
[5.3.1. No wlanX interface?.....21](#)
[5.3.2. No nearby wireless networks?.....21](#)
[5.3.3. No bluetooth devices?.....22](#)

1. Overview

1.1. Contents

This release contains

- u-boot bootloader source code (version 2015.04)
- Linux kernel source code (version 3.14.52)
- WiFi Firmwares (for bcm4329, bcm4330 and bcm4339)
- Bluetooth firmwares (for bcm4329, bcm4330 and bcm4339)
- Broadcom tool for loading bluetooth firmware (including source code)
- Pre-built u-boot and kernel binaries for several configurations
- Release notes PDF (this document)

1.2. Supported products

CPU modules supported by this release include:

- **EDM1-CF-IMX6**
- **EDM2-CF-IMX6**
- **EDM1-CF-IMX6SX** (only the arm-v7 main core is supported)
- **PICO-IMX6-SD**
- **PICO-IMX6-EMMC**
- **PICO-IMX6POP-SD**
- **PICO-IMX6POP-EMMC**
- **PICO-IMX6UL-QSPI** (preliminary support, only arm-v7 core is supported)
- **PICO-IMX7-SD** (preliminary, only arm-v7 core is supported)
- **PICO-IMX7-EMMC** (preliminary, only arm-v7 core is supported)

and supported systems include

- **TC0700**
- **TC0750**
- **TEK3-IMX6**

In addition to these, there are a number of example pre-configured baseboard-module combinations. These include:

- **EDM1-CF-IMX6 + EDM1-FAIRY**
- **EDM2-CF-IMX6 + EDM2-ELF**
- **EDM1-CF-IMX6SX + EDM1-GOBLIN**
- **PICO-IMX6-SD + PICO-DWARF**
- **PICO-IMX6-EMMC + PICO-DWARF**
- **PICO-IMX6POP-SD + PICO-DWARF**
- **PICO-IMX6POP-EMMC + PICO-DWARF**
- **PICO-IMX7D-SD + PICO-DWARF**
- **PICO-IMX7D-EMMC + PICO-DWARF**
- **PICO-IMX6UL-QSPI + PICO-HOBBIT**

additionally this package also offers limited support for the 3rd party boards

- Wandboard (edm1 module + baseboard)
- Mimas (edm1 baseboard)

2. Usage instructions

These instructions assume that a linux command line build environment is used.

2.1. Setting up a build environment

In order to simplify the setup of a cross compiler, TechNexion provides a virtual machine of a Ubuntu Linux. Inside this VM image the cross compilers are already correctly set up. This virtual machine can be downloaded from TechNexion FTP.

Manual setup is slightly outside the scope of these release notes, but essentially three steps have to be taken on Linux computer:

- Download a cross compiler toolchain (linaro project often has recent gcc cross compilers),
- set environment variable `CROSS_COMPILE` to the compiler prefix (i.e arm-none-gnueabi),
- add the path to `$CROSS_COMPILE-gcc` to your `PATH` environment variable, and
- set `ARCH` variable to `arm`.

2.2. Preparing a bootable SD card

TechNexion products are usually bootable from SD card or from an on-board eMMC flash chip. Since these two work the same way in software (the differences are abstracted away by the very low level drivers), this description will guide how to compile the software and how to prepare a bootable SD card. The installation to eMMC should be done in a similar way (so that files are placed in the equivalent locations, but inside the eMMC flash).

First prepare an SD card by partitioning it, leaving the first megabyte (or more) unpartitioned (most modern disk utilities do this by default). The first partition is called the boot partition and should be at least some 7-8MB in size. Larger is no problem, but smaller might be. Make it 16-32 MB if size is not a concern.

The rest of the SD card is to be used as Linux userland and/or swap. Partition accordingly to your needs. Then format the first partition as a FAT32 (also FAT16 or FAT12 should work - and be able to create smaller filesystems).

2.3. U-boot bootloader

This section outlines how to compile and install u-boot for your product.

2.3.1. Compiling u-boot

U-boot is the bootloader responsible for very low-level setup of the board. It initializes RAM and storage so a Linux kernel can be loaded and executed.

To compile u-boot you need to configure u-boot for your product. For your convenience, there are a number of pre-configured settings you can use (highly recommended).

U-boot (in general) is configured by the command

```
% make boardconfig
```

where *boardconfig* is the name of configuration file in `configs/` folder. The exact name depends on the target board/system and is detailed below.

To compile u-boot with pre-configured configurations first 'cd' into the folder with u-boot source code and then issue the commands:

For **EDM1-CF-IMX6**, **EDM2-CF-IMX6** SoMs or **TEK3-IMX6** system

```
% make edm-cf-imx6_defconfig
```

```
% make -j 4
```

For **TC0700** or **TC0750** (note: it is possible, and even recommended to use the EDM1-CF-IMX6 configuration if a serial debug console is used)

```
% make edm-cf-imx6-no-console_defconfig
```

```
% make -j 4
```

For **EDM1-CF-IMX6SX**

```
% make edm1-cf-imx6sx_spl_defconfig
```

```
% make -j 4
```


For **PICO-IMX6-SD**, **PICO-IMX6-EMMC**, **PICO-IMX6POP-SD** or **PICO-IMX6POP-EMMC**

```
% make picosom-imx6_defconfig
```

```
% make -j 4
```

For **PICO-IMX6UL-QSPI**

```
% make picosom-imx6ul_defconfig
```

```
% make -j 4
```

For **PICO-IMX7D-SD** or **PICO-IMX7D-EMMC**

```
% make pico-imx7d_defconfig
```

```
% make -j 4
```

The result from a successful compile is for most products two files. One is named 'SPL' and the other 'u-boot.img'. These are both needed to boot the board.

The exceptions from the above are the **PICO-IMX6UL** and **PICO-IMX7D** that only uses a single-stage bootloader named `u-boot.imx`, and no SPL binary is created.

2.3.2. Installing u-boot

U-boot needs to be installed in boot media, whether it is a bootable SD card or an eMMC flash chip. For most products, this is done in two steps, first install the SPL bootloader and then the main u-boot binary.

The first bootloader, SPL, is installed 1kB into the SD card, outside the partitioned area. This can be done with the 'dd' command:

```
# dd if=SPL of=/dev/sdX bs=1k seek=1 oflag=dsync
```

where `/dev/sdX` is the block device corresponding to the SD card. Note: you need to use the SD card device *itself*, not a partition inside the SD card. The device node name should not end with a number (that indicates it is a partition).

The second bootloader, `u-boot.img`, should be copied into the first FAT partition of your SD card.

NOTE Exception: for **PICO-IMX6UL** and **PICO-IMX7D** there is no SPL bootloader. Instead u-boot is installed with the command:

```
# dd if=u-boot.imx of=/dev/sdX bs=1k seek=1 oflag=dsync
```

where `/dev/sdX` is your SD card device (as above).

2.4. Linux kernel

2.4.1. Compiling the kernel

Like u-boot, the kernel also needs a configuration step. The available configurations are located in `arch/arm/configs/`

It is recommended to start with the configurations and device trees present for some sample configurations.

First change folder ('cd') into the folder with the linux kernel source code. Depending on your product (system or SoM+baseboard combination) issue the commands:

For **EDM1-CF-IMX6** and **EDM2-CF-IMX6** SoMs (on a **EDM1-FAIRY** baseboard):

```
% make edm-cf-imx_defconfig
% make -j4 zImage modules imx6dl-edm1-cf.dtb imx6q-edm1-cf.dtb
```

For **TC0700** and **TC0750** the steps are the same as for **EDM1-CF-IMX6** and **EDM1-FAIRY** (see above), but needs a small manual change to enable correct audio (the board inside **TC0700** and **TC0750**, the EDM1-TOUCAN, uses line out audio, while the **EDM1-FAIRY** uses headphone out).

Edit `arch/arm/boot/dts/imx6qdl-edm1-cf.dtsi`, and change the line

```
"Headphone Jack", "HP_OUT";
```

to

```
"Line Out Jack", "HP_OUT";
```

thereafter proceed as with the **EDM1-CF-IMX6** above:

```
% make edm-cf-imx_defconfig
% make -j4 zImage modules imx6dl-edm1-cf.dtb
```

For **EDM1-CF-IMX6SX** (with a **EDM1-GOBLIN**) baseboard:

```
% make edm-cf-imx_defconfig
% make -j4 zImage modules imx6sx-edm1-cf.dtb
```

For **PICO-IMX6-SD**, **PICO-IMX6-EMMC**, **PICO-IMX6POP-SD** or **PICO-IMX6POP-EMMC** (with a **PICO-DWARF** baseboard):

```
% make picosom-imx6_defconfig
% make -j4 zImage modules imx6dl-picosom.dtb imx6q-picosom.dtb
```

For **PICO-IMX6UL-QSPI** (on a **PICO-HOBBIT** baseboard):

```
% make picosom-imx6ul_defconfig
% make -j4 zImage modules imx6ul-picosom-hobbit.dtb
```

For **TEK3-IMX6** (In software, sometimes called "Box-iMX6"):

```
% make edm-cf-imx6_defconfig
% make -j4 zImage modules imx6dl-box.dtb
```

For **PICO-IMX7D-SD, PICO-IMX7D-EMMC** (on a pico-dwarf baseboard):

```
% make pico-imx7d_defconfig
% make -j4 zImage modules imx7d-pico.dtb
```

2.4.2. Installing the linux kernel, device trees and modules

Install your device tree by copying arch/arm/boot/zImage and all .dtb files in arch/arm/boot/dts/ to the first (FAT) partition of your SD card.

```
# cp arch/arm/boot/zImage arch/arm/boot/dts/*.dtb /mnt/boot/
```

assuming your FAT partition on the SD card is mounted at /mnt/boot.

Kernel modules are installed with

```
# make ARCH=arm modules_install INSTALL_MOD_PATH=/path/to/rootfs
```

where /path/to/rootfs is where your Linux root filesystem is mounted (or located). The modules_install make rule installs the modules in /lib/modules/... folder.

2.5. Installing WIFI and bluetooth firmware

TechNexion products are equipped with different WiFi models depending on product. The **EDM1-CF-IMX6**, **EDM2-CF-IMX6**, **TC0700** and **TC0750** are equipped with a Broadcom 4330 design, and the **PICO-IMX6-SD**, **PICO-IMX6-EMMC**, **PICO-IMX6POP-SD**, **PICO-IMX6POP-EMMC**, **PICO-IMX7D-SD**, **PICO-IMX7D-EMMC**, **EDM1-CF-IMX6SX** and **PICO-IMX6UL** are equipped with a Broadcom 4339 design.

The **TEK3-IMX6** has no WiFi, and most products comes in both versions with and without a WiFi. Check your model!

The wifi driver kernel modules (named `brcmfmac.ko` and `brcmutil.ko` for the `bcm4330`, and `bcmdhd.ko` for the `bcm4339`) should be installed into the `/lib/firmware/brcm/` directory in your Linux root filesystem.

The firmware files needed

a) for `bcm4330` (**EDM1-CF-IMX6**, **EDM2-CF-IMX6**, **TC0700**, **TC0750**) are:

- `brcmfmac4330-sdio.txt`
- `brcmfmac4330-sdio.bin`
- `bcm4330.hcd`

b) for `bcm4339` (**EDM1-CF-IMX6SX**, **PICO-IMX6-SD**, **PICO-IMX6POP-SD**, **PICO-IMX6-EMMC**, **PICO-IMX6POP-EMMC**, **PICO-IMX7D-SD**, **PICO-IMX7D-EMMC** and **PICO-IMX6UL**) are:

- `fw_bcmdhd.bin`
- `bcmdhd.cal`
- `Type_ZP.hcd`

3.0 Usage

3.1. Serial debug console

A common way to access the unit is by using the serial debug feature of ARM boards. Consult the documentation for your board on how to attach a serial cable to your PC, and start a terminal emulator (such as Minicom, Teraterm or Putty).

The terminal settings should be set to 115200 baud, no stop bits, 8 data bits, one parity bit and no flow control.

3.2. Enabling WiFi

This section describes how to manually enable and verify WiFi from the Linux command line.

3.2.1 Loading driver and firmware

For bcm4330 devices (**EDM1-CF-IMX6**, **EDM2-CF-IMX6**, **EDM1-CF-IMX6SX**, **TC0700** and **TC0750**) the driver used is the Broadcom Fullmac driver, and the kernel modules needed to enable wifi are

`brcmfmac.ko` and `brcmutil.ko`. Use the command:

```
# modprobe brcmfmac
```

to load the kernel module. The firmware is loaded when the module is inserted.

The bcm4339 devices (**PICO-IMX6-SD**, **PICO-IMX6-EMMC**, **PICO-IMX7D-SD**, **PICO-IMX7D-EMMC** and **PICO-IMX6UL**) uses the Broadcom DHD driver. The kernel module needed is `bcmdhd.ko` and inserted with

```
# modprobe bcmdhd
```

The firmware is loaded when the module is inserted.

3.2.2 Verifying WiFi operation

First load driver module, and then check that a wireless interface has appeared (issue the command on the board, in a linux console, perhaps in debug console)

```
# ifconfig -a
```

If a wlan* interface is listed (lets call it wlanX), the firmware has been loaded succesfully. Now bring the interface up and perform a scan for networks:

```
# ifconfig wlanX up
```

```
# iwlist wlanX scan
```

A list of wireless networks and their parameters should be displayed,

3.3. Enabling bluetooth

This section describes how to load bluetooth firmware and how to verify bluetooth is working.

3.3.1. Loading bluetooth driver and firmware

The bluetooth part of the wifi chip requires a userland tool to load the firmware, This tool is named `brcm_patchram_plus` and is included as both a precompiled arm hardfloat binary and as source code.

The bluetooth is attached over a serial interface, and while the commands look to load the firmware look similar, there are minor differences in the UART used.

To load the firmware for bluetooth, use the `brcm_patchram_plus` as described for your product, and then proceed with the steps at the end of the section to verify bluetooth functionality.

For **EDM1-CF-IMX6**, **EDM2-CF-IMX6**, **TC0700** or **TC0750**:

```
# brcm_patchram_plus -d --patchram /lib/firmware/brcm/bcm4330.hcd  
--baudrate 3000000 --no2bytes --tosleep=2000 --enable_hci /dev/ttyxc2  
&
```

This command takes a few seconds (less than ten) to execute.

For **EDM1-CF-IMX6SX**,

```
# brcm_patchram_plus -d --timeout=6.0 --patchram  
/lib/firmware/brcm/bcm4330.hcd --baudrate 3000000 --no2bytes  
--tosleep=2000 --enable_hci /dev/ttyxc5 &
```

for **PICO-IMX6-SD, PICO-IMX6-EMMC, PICO-IMX6POP-SD, PICO-IMX6POP-EMMC**,

```
# brcm_patchram_plus -d --timeout=6.0 --patchram  
/lib/firmware/brcm/Type_ZP.hcd --baudrate 3000000 --no2bytes  
--tosleep=2000 --enable_hci /dev/ttyxc1 &
```

for **PICO-IMX7D-SD, PICO-IMX7D-EMMC** and

```
# brcm_patchram_plus -d --timeout=6.0 --patchram  
/lib/firmware/brcm/Type_ZP.hcd --baudrate 3000000 --no2bytes  
--tosleep=2000 --enable_hci /dev/ttyxc3 &
```

for **PICO-IMX6UL-QSPI**

```
# brcm_patchram_plus -d --timeout=6.0 --patchram  
/lib/firmware/brcm/Type_ZP.hcd --baudrate 3000000 --no2bytes  
--tosleep=2000 --enable_hci /dev/ttyxc4 &
```

3.3.2. Verify Bluetooth functionality

Easiest way to verify Bluetooth is to scan for nearby bluetooth devices. Make sure your bluetooth device is broadcasting (usually by pressing a "connect" button or the like). Boot with Linux and on the command line (over debug console) issue the commands

```
# hciconfig hci0 up  
# hcitool -i hci0 scan
```

and a list of nearby bluetooth devices should appear.

4.0 Customization

This section describes some common customizations.

4.1. Display settings

There are two types of display changes: to change the output device (LCD display, HDMI monitor, LVDS panel etc) or change the display settings (resolution, timings).

The output device is controlled by u-boot, and the settings are partially in u-boot but sometimes also in the kernel device tree.

4.1.1. Change output device

To change output device, enter your u-boot (use debug console, and press a key to stop the boot process). A prompt appears. Give commands:

```
=> setenv display_autodetect off
```

and then set your output device with (example commands)

for HDMI (where available):

```
=> setenv displayinfo 'video=mxcfb0:dev=hdmi,1920x1080M@60,if=RGB24'
```

for LVDS (4 lanes, 24 bit interface):

```
=> setenv displayinfo  
'video=mxcfb0:dev=ldb,1024x600@60,if=RGB24,bpp=32'
```

for LCD/TTL:

```
=> setenv displayinfo  
'video=mxcfb0:dev=lcd,800x480@60,if=RGB24,bpp=32'
```

or for a dual LVDS + HDMI display:

```
=> setenv displayinfo  
'video=mxcfb0:dev=ldb,1024x600@60,if=RGB24,bpp=32  
video=mxcfb1:dev=hdmi,1280x720M@60,if=RGB24'
```

To test the changes (without saving), issue the

```
=> boot
```

command.

To save settings, use the

```
=> saveenv
```

command before (re)booting.

4.1.2. Change display parameters

The examples above have resolutions given as CVT timings. These do not always work (even when the panel supports CVT timings). Especially LVDS and LCD panels requires modification of the device tree to set detailed display settings.

The devicetree changes are to be done in kernel source tree, in the `.dts` (or `.dtsi`) file for your product, located in `arch/arm/boot/dts` folder.

In the dts ("device tree source") file, there should be a display section, similar to:

```
display-timings {
    native-mode = <&timing0>;
    timing0: lcd_panel {
        clock-frequency = <51000000>;
        hactive = <1024>;
        vactive = <600>;
        hback-porch = <90>;
        hfront-porch = <90>;
        hsync-len = <130>;
        vback-porch = <5>;
        vfront-porch = <5>;
        vsync-len = <25>;
        de-active = <1>;
        hsync-active = <1>;
        vsync-active = <1>;
        pixelclk-active = <1>;
    };
};
```

Here, the timings of your panel needs to be filled in. These can (hopefully) be found in the datasheet for the panel. To give a quick guide to the commonly used parameters:

- `clock` is the pixel clock in Hz
- `hactive`, `vactive` is the resolution of the display (in pixels).
- `hback-porch`, `hfront-porch`, `hsync-len` are the horizontal timings (in pixel clocks).
- `vback-porch`, `vfront-porch`, `vsync-len` are the vertical timings (also in pixel clocks)
- `de-active` is a 1 or 0 value (boolean) whether to use DE mode or not (for LVDS panels)
- `hsync-active` and `vsync-active` are also 1 or 0 values indicating positive or negative edge for the sync signals
- `pixelclk-active` is also 1 or 0 indicating whether to use positive or negative edge for the pixel clock.

Many panels' datasheets do not give complete timings, but for example listing only numbers for the horizontal total, vertical total and resolution. Then a practical approach is to distribute the difference between the horizontal resolution and horizontal total among the horizontal back porch, front porch and sync length. A heuristic way to guess the values is to assign some 50-60% as sync length, and 20-25% of the total as front and back porch each.

Example: a panel has 1024x768 resolution and 1104 horizontal total. Then a reasonable guess is to have horizontal front porch, back porch and sync lengths as 20, 20 and 40 respectively. Note that total of horizontal resolution and sync lengths (1024+40+20+20) should equal the horizontal total (1104).

A similar division can be done for the vertical porches and sync length.

Recompile the device tree by

```
% make file.dtb
```

and copy it to your boot partition, replacing the existing `dtb` (device tree blob) file.

4.2. Boot splash screen

The boot splash image is built into u-boot, and does not completely initialize the graphics subsystem. It is recommended to use a small image with black borders for best results.

To replace the default splash image with *image.jpeg*, follow the steps below on a ubuntu PC:

Install the needed graphics packages (often already installed) by:

```
# apt-get install netpbm imagemagick
```

Convert the image to 8-bit BMP (with max 128 colors), for instance with:

```
% convert image.jpeg -colors 128 image.ppm
```

and then overwrite technexion.bmp in u-boot source code folder with

```
% cat image.ppm | pnmtojpg -bpp 8 > tools/logos/technexion.bmp
```

Then recompile u-boot (the name of the file embedded into the u-boot binary depends on the name of the folder where the boards resign, see board/ folder).

5.0. Troubleshooting

This section covers some common problems.

Also be noted that you can update your software to the latest published 3.14.52 version by issueing the command

```
% git pull --rebase
```

in either the u-boot or kernel folder. This will retrieve the latest patches from TechNexion git at <https://www.github.com/TechNexion>

5.1. *It is not working!*

Sad to hear that. Whatever you are trying to do, try some of the pre-compiled software images provided by TechNexion and see if *It* is working there.

Then do your changes (like replace u-boot or kernel) on the pre-compiled image, and see if *it* is still working or not.

Doing only one change at a time is a good way to find the source of your problems.

5.2. Debug console problems

5.2.1. There is nothing on the console!

Check:

- Your cable is connected to the right place
- That you have a null modem / gender changer. Try changing to the other kind.
- Your baudrate is 115200 baud (see section 3.1)
- You are using the right serial port on your PC, right?

5.2.2. There is still nothing on the console on my TC0700

By default debug console is disabled on **TC0700**, to avoid interference with equipment connected to the external UART port.

To enable the debug console first try attaching a Prolific or FTDI USB to serial adapters to a USB host port before powering up the board. A few selected USB serial models might provide a serial debug console that way.

If this does not work or is not an option, compile a u-boot for **EDM1-CF-IMX6** and use that on your **TC0700**. The debug console for **TC0700** is enabled there.

5.2.3. Garbage on the console

"Garbage" on the console is a typical sign of baudrate problems. Check your settings.

If the console became garbled during usage, chances are that something (like viewing binary data -- more specifically character "\016") has triggered the 8th bit on mode.

The easiest way to fix this is by either starting a new terminal or (if possible) by issuing the shell command `reset` in a linux terminal (even if typed blindly on a garbled console). Also, displaying the character "\017" (like with the shell command `printf "\017"`) will turn the 8th bit off again.

5.3. Wifi and bluetooth problems

This section contains solutions to a few common wifi and bluetooth problems.

5.3.1. No wlanX interface?

Usually this is due to firmwares not loaded. Check your firmwares are in `/lib/firmware/brcm`. Sometimes this can be due to chip not powered up properly (for products with gpio controlled wifi power) or an rfkill driver blocking the wifi.

5.3.2. No nearby wireless networks?

You do have an antenna connected?

Also be reminded that an antenna for 2.4GHz and 5GHz antenna are different.

5.3.3. No bluetooth devices?

The devices nearby should sometimes be entered into pairing/connect mode.

Also Bluetooth is a short-range network, so while debugging have your bluetooth device next to the board.